



Model No.TR001G Cordless Rebar Tying Tool



Model No.TR001G Cordless Rebar Tying Tool



Model No.TR001G Cordless Rebar Tying Tool

Item No.	Parts No.	Description	Interchangability	Q'ty	New/Old	Note1	Note2
001	262054-7	Urethane ring 3		1			
002	256A96-7	Grooved pin 4B		1			
003	268238-5	Pin 5		1			
004	212009-2	Needle bearing 509		1			
005	1412D2-8	Magazine cover complete		1			
006	232924-4	Compression spring 11		1	*		
006-1	232A45-8	Compression spring 17	S	1			
007	312H72-4	Reel bearing		1			
008	941051-3	Flat washer 4		1	*		
008-1	941001-8	Flat washer 3	S	1			
009	266007-8	Binding head tapping screw 3X10		1			
010	233388-5	Compression spring 5		1			
011	347D47-0	Guide plate		1			
012	266007-8	Binding head tapping screw 3X10		1			
013	4131T9-3	Magazine cover lock		1			
014	262054-7	Urethane ring 3		1			
015	256A93-3	Grooved pin 4A		1			
016	266404-8	Binding head tapping screw 3X14		2			
017	312H73-2	Reel base		1			
018	1410Y0-7	Magnet holder D complete		1			
019	232921-0	Compression spring 4C		1			
020	4131U3-2	Plate cover		1			
021	266404-8	Binding head tapping screw 3X14		2			
022	268136-3	Pin 4		1			
023	232925-2	Torsion spring 4A		1			
024	347D33-1	Side plate		1			
025	911008-8	Pan head screw M3X8 WR		2			
026	1831M0-3	Housing set		1			
C10	263005-3	Rubber pin 6		2			
C20	252126-6	Hex. lock nut M4-7		2			
C30	8091F3-7	Caution label A		1			
C40	8091F5-3	Caution label B		1			
C50	8091F1-1	Indication label		1			
026		INC. 61					
027	256A89-4	Shoulder pin 4C		1			
028	347D30-7	Stopper base		1			
029	232916-3	Torsion spring 4B		1			
030	313610-7	Stopper		1			
031	911008-8	Pan head screw M3X8 WR		1			
032	1410X5-0	Magnet holder C complete		1			
033	911008-8	Pan head screw M3X8 WR		1			
034	232922-8	Compression spring 4B		1			
035	1410Y1-5	Magnet holder A complete		1			
036	4131U6-6	Slide plate cover		1			
037	266007-8	Binding head tapping screw 3X1		1			

		0					
038	347D32-3	Slide plate		1			
039	347D38-1	Slide plate guide		1			
040	266007-8	Binding head tapping screw 3X1 0		1			
041	458219-9	Trigger lock		1			
042	234037-7	Compression spring 5		1			
043	458220-4	Trigger		1			
044	632W63-2	Switch unit		1			
045	1411B8-6	Controller complete		1			
046	632P65-6	Terminal unit		1			
047	911008-8	Pan head screw M3X8 WR		1			
048	266007-8	Binding head tapping screw 3X1 0		1			
049	232922-8	Compression spring 4B		1			
050	1410Y1-5	Magnet holder A complete		1			
051	4131U6-6	Slide plate cover		1			
052	347D32-3	Slide plate		1			
053	266007-8	Binding head tapping screw 3X1 0		1			
054	347D38-1	Slide plate guide		1			
055	313610-7	Stopper		1			
056	347D30-7	Stopper base		1			
057	232916-3	Torsion spring 4B		1			
058	256A89-4	Shoulder pin 4C		1			
059	266130-9	Binding head tapping screw 3X1 6		17			
060	911008-8	Pan head screw M3X8 WR		2			
061	1831M0-3	Housing set		1			
C10	263005-3	Rubber pin 6		2			
C20	252126-6	Hex. lock nut M4-7		2			
C30	8091F3-7	Caution label A		1			
C40	8091F5-3	Caution label B		1			
C50	8091F1-1	Indication label		1			
061		INC. 26					
062	266404-8	Binding head tapping screw 3X1 4		2			
063	4131U3-2	Plate cover		1			
064	347D33-1	Side plate		1			
065	268136-3	Pin 4		1			
066	232925-2	Torsion spring 4A		1			
067	266007-8	Binding head tapping screw 3X1 0		2			
068	266490-9	Pan head tapping screw 2X6		3			
069	652069-6	Flat head screw M3X6		3			
070	629D10-8	Stator		1			
071	619896-4	Rotor		1			
072	122K70-6	Twist assembly		1			
073	266490-9	Pan head tapping screw 2X6		3			
074	629D11-6	Stator		1			
075	652069-6	Flat head screw M3X6		3			
076	619897-2	Rotor		1			
077	256A08-0	Pin 5		1			

078	122K54-4	Curl guide assembly		1		
079	1411G5-7	Cutter complete		1		
080	232923-6	Compression spring 4D		1		
081	347D29-2	Cutter base		1		
082	313613-1	Wire bender		1		
083	313606-8	Cutter guide		1		
084	265634-8	Hex. socket head bolt M3X8		4		
085	313608-4	Wire guide B		1		
086	347D34-9	Curl guide C		1		
087	265634-8	Hex. socket head bolt M3X8		1		
088	327E72-3	Shoulder sleeve 4B		1		
089	122K71-4	Release lever assembly		1		
090	253623-5	Flat washer 9		1		
091	327E71-5	Shoulder sleeve 4A		1		
092	922147-9	Hex. socket head bolt M4X25		1		
093	122K72-2	Feed gear base assembly		1		
094	232919-7	Compression spring 6		1		
095	253632-4	Flat washer 7		2		
096	137328-4	Spur gear 21 assembly		2		
097	253077-6	Flat washer 6		2		
098	961011-9	Stop ring (EXT) E-4		2		
099	313603-4	Wire guide A		1		
100	266080-8	Hex. socket head bolt M3X12		2		
101	4131T8-5	Gear cover		1		
102	265E18-0	Hex. socket head bolt M3X17		1		
103	8151G5-0	Name plate TR001G		1		
104	8151G9-2	Serial No. label TR001G		1		
A01	194381-3	Oil vessel set		1		
A02	266622-8	Truss head screw M4X12		1		
A03	347D31-5	Hook		1		
A04	783208-8	Hex. wrench 2.5		1		
A05	821552-6	Connector plastic case (type 4)		1		
C10	453974-8	Latch		4		
A06	836433-1	Inner tray		1		
A07	***DC40RA	DC40RA FAST CHARGER		1		
A07		COMPO-PARTS				
A09B	191B26-6	Battery BL4040 set		2		
A09C	1917Y6-7	Battery BL4040F set		2		
F01	1915N0-0	Tie wire set		1		
F02	1915N1-8	Galvanized tie wire set		1		
F03	1915N2-6	Poly coated tie wire set		1		
F04	1915N3-4	Stainless steel tie wire set		1		
F05	1915N6-8	Extension handle set		1		

Please state Parts No. when your order.

Print Date 05/25/2026